

 **MONSTER®**

TRUE WIRELESS
EARBUDS WITH CHARGING CASE
AURICULARES TWS CON ESTUCHE DE CARGA



Model: 2MNTW0245B0A4

CHARGING THE CASE

Connect the USB Type-C charging cable into the socket on the Charging Case.

Plug the cable into a standard USB 5V/1A output.

The case LED screen will show the battery charging states while the case is charging and will show 100% states when fully charged.

When fully charged, unplug the charging cable.

Warning: To avoid damage to the Charging Case, please only use a 5V/1A charger.

CHARGING THE EARPHONES

Put the Earphones into the Charging Case. The LED screen will show "L" or "R", indicating that the charging prongs are fully contact.

Close the charging case lid, the Earphones LED indicator will stay red while the earphone are charging, when charging is complete the LED will turn off completely. (Note: the Earphones come with a built-in rechargeable battery. Before using them for the first time, we recommend you fully charge the battery. A full charge takes around 1 hour).

The case LED screen will show the earbuds battery states when the earbuds are put into the case, left side shows left earbud battery states, right side shows right earbud battery states.

WARNING: The Earphones can only be used with the provided Charging Case

BLUETOOTH PAIRING

1. Go to "Bluetooth" Settings on your Bluetooth device (phone, tablet, etc.).
2. Turn the Bluetooth ON, on your device.
3. Open the charging case, they will automatically turn on (or they can be turned on manually). The LED indicators on the

1. left and right Earphones will flash blue and red as they automatically sync to each other. Once synced the Earphones will enter pairing mode, which is identifiable by one earbud flashing blue and red.
2. On your Bluetooth Device, select the pairing name of your Earphones on the list of available devices.
3. Pairing name is: Monster Stream Air
4. The Earphone LED indicator will slowly flash blue once connected.

Trouble shooting tip: if the Earphones do not connect to your device, turn the Earphones OFF, turn your device's Bluetooth OFF and then back ON, then repeat the pairing process).

Your Earphones are designed to automatically sync to each other when they are turned ON, however if they ever fail to sync, please follow the below instructions to re-sync the left and right Earphones:

1. Remove the Earphones from the charging case, ensuring both Earphones are turned ON.
2. Press both right and left Earphone buttons 5 times in quick succession. The Earphone LED indicators will flash blue 3 times and then the Earphones will turn off.
3. Put the Earphones into the charging case, then you can repeat the above pairing process.

PHONE CALLS

If there is an incoming call on your Bluetooth device, the Earphones will pause any playback and ring to alert you of the call. To answer the call, press either Earphone button. To end a call, press the either Earphone button again.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Warranty

What is covered under the 2 Year Warranty?

Monster® warrants that this product will be free from defects in workmanship and materials under normal use (Limited Warranty"). In a case where the product is determined to be "defective", we will repair the product free of charge. If we cannot repair the product, we will replace it for you free of charge.

How long am I covered?

You are covered for the 2 Years from Purchase


What is not covered under the Limited Warranty?

1. Normal wear and tear of product use.
2. Misuse, lack of care, mishandling, accidental damage, abuse or other abnormal use.
3. Use of the product other than for its intended purpose.
4. Damage caused by improper or unauthorized repair or maintenance.
5. Product that has been modified or altered.
6. Any product that is not manufactured by Monster® (including, without limitation, any non-Monster® product that is used in connection with the product).

CONTROLS




Contact with
charging prongs




LED indicator

Earphone button
power / phone



Charging Case
LED digital display




USB-C charging port

Earphone Function Operation

Pause Press either  button

Play Press either  button

Next Track Press the right  button 3 times in quick successions

Previous Track Press the left  button 3 times in quick successions

Answer Call
Press either  button

Reject Call
Press and hold either  button

End Call
Press either  button


Power ON

Press and hold  button (on each Earphone) for 5 seconds


Power OFF

Press and hold  button (on each Earphone) for 6 seconds

Activating Phone Assistant

Press and hold either  button for 2 seconds

Volume Up Press the right  button 2 times in quick successions

Volume Down Press the left  button 2 times in quick successions

SPECIFICATIONS

Model No:

2MNTWO245BOA2

Version:

5.3 Bluetooth chipset

Support profiles:

A2DP, AVRCP, HFP

Working distance:

10 Meters

Music time:

>7 Hours

Talk time:

>5 Hours

Standby time:

>20 Hours

Charging voltage:

5V d.c.

Battery capacity

(Charging Case):

500mAh

Charge time

(Charging Case):

2 Hours

Battery capacity

(Earphones):

2 x 45mAh

Charge time

(Earphones):

1 Hour approx

Pairing window time:

5 Minutes

Pairing name:

Monster Stream Air

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc.
CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



WARNING Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.

5060/9

website: monsterstore.com
support: support@monsterforever.com

2 Year Limited Warranty

Package Contents: (1) TWS earbuds with charging case, (2) pairs eartips (Sm,Lg), (1) USB-C™ charging cable, (1) user manual

Manufactured and distributed by Lifeworks technology Group LLC, under license. New York, NY 10018. ©2023. The M Monster logo and the M slice logo are trademarks or registered trademarks of Monster Inc. and its subsidiaries in the U.S. and other countries and are used under license. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. USB-C is a registered trademark of USB Implementers Forum. Other trademarks and trade names are those of their respective owners. MADE IN CHINA



WARNING: This product can expose you to chemicals including Lead and Lead Compounds, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

ADVERTENCIA: Este producto puede exponerle a químicos incluyendo Lead and Lead Compounds, que es (son) conocido (s) por el Estado de California como causante (s) de cáncer y defectos de nacimiento u otros daños reproductivos. Para mayor información, visite www.P65Warnings.ca.gov.

